


# AIR MAGIC ARM INSTRUCTIONS

COPYRIGHT © PIXELLOT 2023

Oct 2023, Version 2



Congratulations on receiving your Pixellot Air camera! If you're utilizing the Magic Arm, please follow the instructions below on how to set it up.


**Confirm Your Hardware**

- Magic arm piece (on left)
- Magic arm clamp (on right)




## Connecting the Magic Arm

First, loosen the knob circled in red. This will allow you to extend the arm out as shown below.



Next, input the piece circled below into the clamp. The screw side should stay showing.



On the clamp, press the silver lever on the left to allow the Magic Arm to connect.



The Magic Arm should look like this once connected.



Tighten the smaller knob on the clamp to secure the connection.



Attach the Magic Arm to an object like a fence, bleacher seat or railing. The clamp opens to a max of 2 inches. The knob circled in red can be used to tighten the clamp.





Screw the angle adapter onto the top of the Magic Arm.





Attach the camera to the angle adapter.



If you have any questions, please reach out to our support team: [you.support@pixellot.tv](mailto:you.support@pixellot.tv)